

SOFT HEADPHONES YOU CAN WEAR IN BED, *COMFORTABLY*.

SleepPhones®

fall asleep faster

relax with music

drown out noises

wake up refreshed



SleepPhonesPackageInsert.indd 1 4/11/12 12:02 PM



Fall asleep faster by listening to music with exquisitely soft SleepPhones®—the world's most comfortable headphones for sleeping.

A FAMILY PHYSICIAN developed these innovative, high-quality headphones to help her patients sleep without drugs.*

SleepPhones® can **DROWN OUT NOISES** from loud neighbors and snoring partners, too! Listen to music, meditation, audiobooks, hypnosis, or even the TV in bed.

- Plugs into any standard music player, including iPods, MP3 players, and CD players
- Contains thin removable padded speakers
- Machine washable wicking headband
- Comfortable even for side-sleepers



CARE INSTRUCTIONS

Remove speakers before washing fleece headband. Machine wash warm. Tumble dry medium. Do not iron, bleach, or dry clean. Avoid fabric softener which reduces wicking.

Insert the speakers when the band is dry. The right speaker is red and the left speaker is green. The white side should be against your ears. Insert speakers about four inches, then insert the gray square before closing the Velcro. Adjust to fit.

Visit www.sleepphones.com/video for video instructions.

LIMITED ONE-YEAR WARRANTY

SleepPhones" are warranted to be free from manufacturing defects for one year from the date of purchase. The customer is responsible for shipping 1) the defective part(s) and 2) th receipt showing the date of purchase to AcousticSheep, LLC, PO Box 298, Bellefonte, PA 16823, USA.

We will examine, repair, or replace parts. This warranty does not cover product failures caused by abuse, inappropriate cleaning, or events beyond our control.

SPECIFICATIONS

FLEECE BAND:

Polartec® Power Stretch® (88% recycled polyester, 12% spandex)

SPEAKERS:

120cm (48") cord, 3.5mm (1/8") stereo olug, Impedance: 32 Ω, Frequency: 20-20 kHz, Power: 300/500 mW, RoHS compliant (lead-free), made in China

WARNING: SLEEPPHONES MAY BE A STRANGULATION HAZARD.
THEY SHOULD NOT BE USED BY CHILDREN, THE ELDERLY,
OR BY ANYONE WHO MAY STRANGULATE ON THE CORD.

^{*} This product has not been evaluated by the Food and Drug Administration. This product is not intended to diagnose, treat, cure, or prevent disease. If you are pregnant, nursing, taking medication, or have a medical condition, please consult your doctor before using this product.